

GL1500 Aspencade and Interstate Radio Speaker Wiring and Connectors

There is a 4-pin White connector (C301) that comes from the radio, it has the following four wires:

- 1) Blue/Green. (Front left speaker output "+")
- 2) Gray/Black. (Front left speaker output "-")
- 3) Red/Green. (Front right speaker output "+")
- 4) Brown/Black. (Front right speaker output "-")

There is a 4-pin black connector (C303) that goes to the rear speakers with the following four wires.

- 1) Blue/White. (Rear left speaker output "+")
- 2) Gray/White. (Rear left speaker output "-")
- 3) Red/Yellow. (Rear right speaker output "+")
- 4) Brown/White. (Rear right speaker output "-")

Note: The C301 and C303 connectors are located on the left side of the air filter housing box.

Your Fader control switch should be making connections between the appropriate wires (depending on how it is set).

You could check input/output at that Fader control switch.....!!